

# Meine Grafikkarte wird nicht durchgereicht

Beitrag von „dux13“ vom 7. Mai 2022, 17:19

[Zitat von al6042](#)

Welche Grafik-Details werden denn bei der VM unter "Systeminformationen" angezeigt?

Entschuldige meine Ignoranz aber wo finde ich die "Systeminformationen"? Einerseits habe ich mein Proxmox auf Englisch und wenn ich dies Google finde ich auch keine wirklich hilfreichen Infos.

Einzig dies könnte ich zeigen. Ev. hilft's...

Virtual Machine 111 (Mac) on node 'hcl01'

	Summary	Edit	Revert
>_ Console	Name	Mac	
Hardware	Start at boot	No	
Cloud-Init	Start/Shutdown order	order=any	
Options	OS Type	Other	
Task History	Boot Order	virtio0	
Monitor	Use tablet for pointer	Yes	
Backup	Hotplug	Disk, Network, USB	
Replication	ACPI support	Yes	
Snapshots	KVM hardware virtualization	Yes	
Firewall	Freeze CPU at startup	No	
Permissions	Use local time for RTC	Default (Enabled for Windows)	
	RTC start date	now	
	SMBIOS settings (type1)	uuid=ce2e672f-0d1d-4292-e42a-d242e856993	
	GEMU Guest Agent	Default (Disabled)	
	Protection	No	
	Spice Enhancements	none	
	VM State storage	Automatic	

Oder das...

Virtual Machine 111 (Mac) on node 'hcl01'

	Summary	Add	Remove	Edit	Disk Action	Revert
>_ Console	Memory	16.00 GiB				
Hardware	Processors	16 (2 sockets, 8 cores) [Penny]				
Cloud-Init	BIOS	OVMF (UEFI)				
Options	Display	Default				
Task History	Machine	q35				
Monitor	SCSI Controller	VirtIO SCSI				
Backup	Hard Disk (virtio0)	local-zfs:vm-111-disk-1,size=250G				
Replication	Network Device (net0)	virtio=AA:48:D9:07:FE:15,bridge=vmbrio,firewall=1				
Snapshots	EFI Disk	local-zfs:vm-111-disk-0,efitype=4m,size=1M				
Firewall	PCI Device (hostpci0)	0000:03:00.pcie=1,rombar=0,romfile=Asus.R06800XT.16384.201104.rom				
Permissions						

Danke

Dux