

Erledigt

Ozmosis problem with ASUS MAXIMUS VII HERO

Beitrag von „cs313307987“ vom 10. Juni 2017, 06:22

Schauen Sie sich die Screenshots herunterzufahren , nachdem das BIOS über eine mit [Mod für das Z97 Maximus VII Hero](#)

Beitrag von „al6042“ vom 10. Juni 2017, 09:55

Versuchst du 10.12.5 zu installieren?

Dann kann es daran liegen, der SMCHelper, bzw. der FakeSMC im ROM zu alt ist.

Da hilft es vielleicht, den folgenden Kext unter /EFI/Oz/Darwin/Extensions/Common auf der versteckten EFI-Partition zu platzieren:

[FakeSMC.kext](#)

Beitrag von „Fredde2209“ vom 10. Juni 2017, 11:40

Herunterfahren??

Im Bios sieht es so aus:



Boot Option	File	File Name	File Path
0. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
1. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
2. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
3. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
4. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
5. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
6. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
7. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
8. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
9. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
10. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
11. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
12. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
13. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
14. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
15. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
16. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
17. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
18. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
19. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
20. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
21. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
22. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
23. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
24. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
25. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
26. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
27. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
28. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
29. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
30. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
31. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
32. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
33. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
34. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
35. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
36. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
37. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
38. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
39. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
40. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
41. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
42. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
43. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
44. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
45. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
46. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
47. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
48. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
49. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
50. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
51. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
52. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
53. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
54. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
55. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
56. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
57. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
58. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
59. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
60. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
61. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
62. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
63. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
64. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
65. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
66. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
67. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
68. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
69. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
70. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
71. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
72. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
73. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
74. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
75. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
76. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
77. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
78. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
79. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
80. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
81. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
82. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
83. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
84. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
85. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
86. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
87. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
88. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
89. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
90. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
91. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
92. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
93. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
94. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
95. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
96. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
97. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
98. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
99. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000
100. BOOT0000-0000-0000-0000-00000000	F130	00000000	00000000

Ich wüsste jetzt nicht, was ihm fehlt. Ich kann aber gerne (falls es doch ums hochfahren geht) mal noch das Theme herausnehmen und dafür vielleicht noch ein paar andere Sachen

einfügen. Allerdings ist es eigentlich so, dass ich ROMs erst hochlade, sobald sie getestet wurden. Deshalb würde ich spontan sagen, dass diese Version eigentlich funktionieren sollte

Beitrag von „al6042“ vom 10. Juni 2017, 11:44

Wir wissen aber auch, dass einige Systeme unter 10.12.5 Schwierigkeiten mit älteren FakeSMCs haben können.

Dein ROM ist vom April, während im Mai 10.12.5 raus kam...

U.U. gibt es hier die Überschneidung.

Beitrag von „Fredde2209“ vom 10. Juni 2017, 12:07

Dann könnte ich das hier anbieten:



File Name	Path	File Type	File Location
AppleALC	EFI/AppleALC	File	AppleALC
Lilu	EFI/Lilu	File	Lilu
OzmosisHorizontalTheme	EFI/OzmosisHorizontalTheme	File	OzmosisHorizontalTheme
PartitionDXE	EFI/PartitionDXE	File	PartitionDXE
DisablerKext	EFI/DisablerKext	File	DisablerKext
newFakeSMC (vom 7.6.17)	EFI/newFakeSMC	File	newFakeSMC
EXTFS	EFI/EXTFS	File	EXTFS

- AppleALC
 - Lilu
 - OzmosisHorizontalTheme
 - + PartitionDXE
 - + DisablerKext
 - + neue FakeSMC (vom 7.6.17)
 - +EXTFS
-

Beitrag von „cs313307987“ vom 11. Juni 2017, 07:13

Ich komme aus China Also bitte nicht verstehen Deutsch Verständnis

Nach der Installation 10.12.5 Position auf dem Bild den Computer herunterzufahren , mit der BIOS [Mod für das Z97 Maximus VII Hero](#) ist -VII-Hero / Computerkonfiguration geschossen hat der Gott mir bitte helfen, Dank zu finden!

Installation 10.12.5 Fotos nach der position MIT BIOS ist der computer aus [Mod für das Z97 Maximus VII Hero](#)
Mein computer zur Verfügung haben, Mir zu helfen, dank der "screenshot bitte!!!!!!"

Install 10.12.5, the code scroll to the location on the picture after the automatic shutdown, the BIOS is [Mod für das Z97 Maximus VII Hero](#) Z97-Maximus-VII-Hero / My computer configuration has been screenshots, please help me look great God, thanks!

Beitrag von „jboeren“ vom 11. Juni 2017, 08:26

Hello!

I don't know if I can help you...

Can you write your problem in english?

Which cpu do you have? The screenshot says it's not supported...

Beitrag von „cs313307987“ vom 11. Juni 2017, 08:38

Install 10.12.5, the code scroll to the location on the picture after the automatic shutdown, the BIOS is [Mod für das Z97 Maximus VII Hero](#) Z97-Maximus-VII-Hero /
My computer configuration has been screenshots, please help me look great God, thanks!

Beitrag von „al6042“ vom 11. Juni 2017, 09:57

It seems to be the same problem with the Sierra based Ozmosis ROMs created prior to the release date of macOS Sierra 10.12.5...

Try to boot with a linux USB stick and put the following FakeSMC.kext into the hidden EFI-Partition of your HDD or SSD.

[FakeSMC.kext](#)

This file must be placed into the folder /EFI/Oz/Darwin/Extensions/Common.

Beitrag von „Fredde2209“ vom 11. Juni 2017, 09:59

Why dont you just start your Computer again afterwards? During the Installation process, it makes multiple restarts!

Beitrag von „al6042“ vom 11. Juni 2017, 10:08

[@cs313307987](#)

I justed combined your two threads into one...

[@Fredde2209](#) gave you a new Ozmosis-ROM already... Didn't you try that one?

Beitrag von „cs313307987“ vom 11. Juni 2017, 10:31

yes! Fredde2209 gave me a new Ozmosis-ROM is the same problem!

Beitrag von „al6042“ vom 11. Juni 2017, 10:36

Then try the solution I mentioned before, with the FakeSMC in /EFI/Oz/Darwin/Extensions/Common.

Beitrag von „cs313307987“ vom 11. Juni 2017, 10:42

I tried the same question, too

Beitrag von „al6042“ vom 11. Juni 2017, 10:43

I do not understand your last post...

Beitrag von „cs313307987“ vom 11. Juni 2017, 10:46

I try the solution I mentioned before, with the FakeSMC in /EFI/Oz/Darwin/Extensions/Common
But it's the same question

Beitrag von „al6042“ vom 11. Juni 2017, 10:50

Would you please add your hardware Information either in your signature or your profile, in the section "about me", so we can have a look at your Details without scrolling to the beginning of this thread?

It would also be helpful to have your current Defaults.plist as an attached file.

Beitrag von „cs313307987“ vom 11. Juni 2017, 11:03

I have added my hardware information, please help me analyze what is the problem! very much...

Beitrag von „al6042“ vom 11. Juni 2017, 11:11

Thanks for the hardware details, now let's please see your Defaults.plist.

Beitrag von „cs313307987“ vom 11. Juni 2017, 11:27

Where's this file? Defaults.plist

Beitrag von „jboeren“ vom 11. Juni 2017, 11:31

It should be in /EFI/Oz/

Beitrag von „al6042“ vom 11. Juni 2017, 11:32

It should be in /EFI/Oz, but it's also possible, that it still resides within the ROM itself.
In that case, you would be able to extract it with the following tool:

[Auslesen der Ozmosis-Parameter](#)

Open it up and use the first button on the right side.

This should create a Ozmosis-folder on your desktop, which contains a rudimentary Defaults_XXXXX.plist, which you can attach to your next post.

Beitrag von „cs313307987“ vom 11. Juni 2017, 11:54

Is it this one

Beitrag von „al6042“ vom 11. Juni 2017, 12:06

yes... that's the one...

would you please use the following command in your terminal and post the resulting file (ifconfig.txt) as attachment?

Code

1. ifconfig > ~/Desktop/ifconfig.txt
-

Beitrag von „cs313307987“ vom 11. Juni 2017, 13:18

Is it this one

Beitrag von „al6042“ vom 11. Juni 2017, 13:23

That's the correct one..

I've attached a new Defaults.plist for your System, which you should put to /EFI/Oz and then do an NVRAM-Reset.

The NVRAM-Reset is done by using and holding the following keys while the System is either in the BIOS or the Boot-Selection:

Alt+WinLogo+P+R

The System should reboot and startup with the Ozmosis-Logo... Good Luck

Beitrag von „cs313307987“ vom 11. Juni 2017, 13:31

thank you very much for your help! I'm going to try now!

Beitrag von „jboeren“ vom 11. Juni 2017, 13:32

wish you Good luck!

Beitrag von „cs313307987“ vom 11. Juni 2017, 13:57

There was an error! Appears on the picture after the last line of code, it automatically shut down

This line of code appears every time it is automatically shut down →→→→→ **CPU halted**

Beitrag von „al6042“ vom 11. Juni 2017, 14:15

Are you trying to install another OSX as a dualboot?

Beitrag von „cs313307987“ vom 17. Juni 2017, 03:54

yes,I tried the same problem,!

Beitrag von „Isolonkin“ vom 3. September 2017, 12:02

Servus,

die neue Rom von Freddy endet leider in einem Blackscreen. Man kommt nicht mal mehr ins bios.