

Erledigt Z97X-UD3H & GTX 760

Beitrag von „al6042“ vom 3. Oktober 2016, 18:07

You don't have to create a new BIOS with the sysdef iMac14,2...
Settings and the SysDef in Ozmosis can be changed with the use of a defaults.plist,

Use the attached file and place it on your hidden EFI-Partition in the directory /EFI/Oz then reboot.

Go into your BIOS or your Boot Selection Menu and use the keyboard combination "Alt+WinLogo+P+R" to do a NVRAM-Reset.

This will reboot your machine again but also reloads the Ozmosis part including the new Defaults.plist settings...