

Erledigt

Ozmosis for z77mxquoaos?

Beitrag von „YogiBear“ vom 1. November 2016, 19:50

Yes, you need to reset your NVRAM to activate the defaults.plist. Without any information about your hardware it's difficult to predict problems with a changed SMBIOS...