

Erledigt

## Flashed Ozmosis: Boots into BIOS ok - Windows does not boot

Beitrag von „griven“ vom 17. Mai 2018, 23:16

But OZ uses it's own config file called Defaults.plist.

A sample config is build into any OZ Rom but it's at least only a sample. OZ needs to be configured and customised as well as clover does. In macOS versions prior to HighSierra the sample config was enough to install and run macOS but with HighSierra Apple introduced some more restrictive firmware checks so we need to make sure our SMBIOS information is always up to date which is pretty impossible to assure with pre made ROMS. The best think you can do is to add your own defaults.plist ([defaults.plist](#)) into /EFI/Oz and keep this thing always up to date. The attached one is ready to be used right away (made it yesterday). To apply the defaults boot into Bios Setup and perform a 4 Finger P-Ram rest (alt+cmd+p+r).