

**Erledigt**

## **Flashed Ozmosis: Boots into BIOS ok - Windows does not boot**

**Beitrag von „al6042“ vom 18. Mai 2018, 20:18**

Hi,

the EFI is a hidden partition on your hdd/ssd.

Either use the small app [ESP Mounter Pro 1.6](#) or find your way through our german FAQ -> <https://www.hackintosh-forum.de/faq/180-efi-mounten/>

The "4-Finger-PRAM/NVRAM-Reset" also works on Ozmosis-based Hackintosh machines, but you have to use it in one of the following stages:

- in your BIOS
- While in the BIOS boot-selection
- While in the Ozmosis boot selection.

The combination on a Hackintosh would be "Alt+WinLogo+P+R"...