

**Erledigt**

## **Who can help me convert the default.plist (Clover to Ozmosis) ?**

**Beitrag von „al6042“ vom 30. Juni 2018, 15:39**

In that case try these two files...

Defaults.plist belongs to the folder /EFI/Oz.

KernextPatcher.plist belongs to the folder /EFI and only works, if the KernextPatcher.efs is also part of the Ozmosis-ROM.