

**Erledigt**

## **Flashed Ozmosis: Boots into BIOS ok - Windows does not boot**

**Beitrag von „alecwild“ vom 17. August 2018, 19:41**

Griven - I've been using your Ozmosis Bios mods for my Z97XUD5H since Yosemite, and have now been running Sierra successfully all year. Thank you!

I'd like to update to High Sierra - I've put UnSolid.kext on the EFI volume of my SSD. Is it OK to use the HighSierra.F10.rom that you posted, or do I need it without APFS build? Also, with your builds, I've never had to bother much with Defaults.plist or SMBIOS, but I read above that these need to be specific with High Sierra. What do I need to do?

Thanks for the help - I'm sorry for my lack of German!