

Opencore Black Screen BIOS

Beitrag von „WeWin“ vom 16. Juni 2020, 11:07

Hi,

danke für die vielen Meinungen und Anregungen. Ich werde heute Abend nach der Arbeit folgenden Dingen probieren:

0. Ausbau der AMD RX560.
1. richtiger CMOS Reset.
2. Anderes Netzteil.
3. Mainboard Lautsprecher um die Bios-Error Töne zu hören. [Wikipedia](#)

Ansonsten fallen mir keine anderen Lösungen mehr ein.

Bei den ganzen Tests hier oben habe ich alle Festplatten, PCIe-Geräte vom Mainboard entfernt. Lediglich CPU, CPU Kühler und 2x Gehäuse Lüfter sind angeschlossen.

Zu 1 von Gigabyte direkt:

You may clear the CMOS values by removing the battery:

1. Turn off your computer and unplug the power cord.
2. Gently remove the battery from the battery holder and wait for one minute.
(Or use a metal object like a screwdriver to touch the positive and negative terminals of the battery holder, making them short for 5 seconds.)
3. Replace the battery.

4. Plug in the power cord and restart your computer.

Ist das der richtige Weg CMOS zu resetten?

Motherboard Handbuch

https://download.gigabyte.com/...al_ga-z97mx-gaming5_e.pdf