

# Lenovo Thinkpad T530

Beitrag von „5T33Z0“ vom 24. Oktober 2020, 13:04

[PDM](#) Here you go. I had this processor too before upgrading to an i7. Rename to SSDT-PM and replace the file in ACPI Folder.

This is a modified version. The stock version ssdtPRGen generates has a higher idle Frequency of 1200 mHz, but this processor clocks down to 800 mHz. Since using 800 prevents the system from booting I set it to 900 mHz which works fine.

Then, Open Config and change the following settings to improve Power Management (my online config doesn't have these yet):

ACPI > Delete > Drop CpuPm > Enabled = YES

ACPI > Delete > Drop Cpu0Ist > Enabled = YES

Kernel > Quirks > AppleXcpmCfgLock = NO (not necessary)

AppleXcpmExtraMsrs = YES (should be yes already)

Kernel > Quirks > AppleXcpmForceBoost = NO (if enabled, Turbo doesn't clock down in idle.)