

# Gigabyte Z390 DESIGNARE: OpenCore-EFI-Ordner und Anleitung

Beitrag von „crazycreator“ vom 19. November 2020, 01:18

Also das Designare hat 2x NVME Anschluss und 6x SATA ... Bei Anschluss einer NVME geht SATA 4 u. 5 und wenn ich den 2ten NVME auch noch nutze gehen auch noch SATA 0 und 1 flöten.

## Installation Notices for the M.2 and SATA Connectors:

Due to the limited number of lanes provided by the Chipset, the availability of the SATA connectors may be affected by the type of device installed in the M.2 sockets. The M2M connector shares bandwidth with the SATA3 4, 5 connectors. The M2P connector shares bandwidth with the SATA3 0, 1 connectors. Refer to the following tables for details.

### • M2M:

Connector Type of M.2 SSD	SATA3 0	SATA3 1	SATA3 2	SATA3 3	SATA3 4	SATA3 5
M.2 SATA SSD	✓	✓	✓	✓	✗	✗
M.2 PCIe SSD	✓	✓	✓	✓	✗	✗
No M.2 SSD installed	✓	✓	✓	✓	✓	✓

✓ Available, ✗ Not available

### • M2P:

Connector Type of M.2 SSD	SATA3 0	SATA3 1	SATA3 2	SATA3 3	SATA3 4	SATA3 5
M.2 SATA SSD	✓	✗	✓	✓	✓	✓
M.2 PCIe SSD	✗	✓	✓	✓	✓	✓
No M.2 SSD installed	✓	✓	✓	✓	✓	✓

✓ Available, ✗ Not available