

# HP EliteBook 840 G1 & OpenCore Catalina/Big Sur

Beitrag von „Franck“ vom 21. September 2021, 05:51

Hello [Hecatomb](#)

just tested the order you have suggested. I didn't add the part:

- VoodooI2C.kext
- VoodooRMI.kext / Sommaire / PlugIns / RMII2C.kext

The HP 840G3 now can have the trackpad working but the click is not active.

How do I know if My hardware is SMBUS or I2C ? Or should I add both parts ?

thanks