

Lenovo ThinkPad E550

Beitrag von „5T33Z0“ vom 10. Oktober 2021, 18:20

Code

1. Original path: PciRoot(0x0)/Pci(0x1C,0x1)/Pci(0x0,0x0) 2
2. Path after internal conversion: PciRoot(0x0)/Pci(0x1C,0x1)/Pci(0x0,0x0)
3. DeviceProperties->Add[1]->DevicePath is borked! Please check the information above!
4. CheckDeviceProperties returns 1 error!

Musste mal ansehen