

# Huananzi x79 Dual CPU C602 Board & DDR3 RAM - Hackintosh Monterey 12.0/Windows 11 DevBeta mit OpenCore 0.7.0

Beitrag von „robcodemax“ vom 16. Dezember 2021, 03:55

[Zitat von haingo](#)

I have tried to use your EFI with DSDTFULLPATCHED you gave along with SSDT-PMC and SSDT-PLUG generated by SSDTTime. But there is no option to boot into installer. I put the recovery image in com.apple.recovery.boot folder as mentioned [here](#) and it does show an option to boot into that with my EFI.

Though there are many SSDT files in your ACPI folder, there only 3 of them are used in your config.plist: SSDT-UNC, SSDT-EC-DESKTOP, SSDT-EC-USBX. So I have to modify the your config.plist to add 2 entries for SSDT-PMC and SSD-PLUG.

The question is: Do I need to keep your 3 files above in the modified config.plist?

PLUG, PMC, UNC and DSDT is enough. Rest everything is already added in DSDT.

If you are unable to see your EFI then

**config.plist -> Misc -> Boot -> HideAuxiliraly Disable it**

Also insert the pendrive in USB 2.0

You are not able to even boot or you are stuck in boot screen or what is the error message ?