

Huananzi x79 Dual CPU C602 Board & DDR3 RAM - Hackintosh Monterey 12.0/Windows 11 DevBeta mit OpenCore 0.7.0

Beitrag von „haingo“ vom 18. Dezember 2021, 10:11

[Zitat von robcodemax](#)

Now just use SSDT-PLUG and SSDT-X79 nothing else and check

You mean SSDT-PLUG, SSDT-PM and SSDT-X79? It's still no use for me.

[Zitat von robcodemax](#)

Also while creating SSDT-PM you need to have two options enabled in the ACPI>Delete section

1. First enable those two options in the ACPI>Delete section and reboot
2. Now create SSDT-PM
3. Disable those two options and then reboot

Yes, I followed that