

Erledigt

Windows 8.1 doesn't show up in Ozmosis GUI or in BIOS

Beitrag von „al6042“ vom 1. Februar 2015, 22:31

You have to do an NVRAM Reset to clean the current settings:

Reset NVRAM via the following key combo: "Option+Command+P+R" either from F12 menu, Ozmosis GUI, Shell or BIOS Setup.