

Erledigt

How to enable IGFX? (Mavericks)

Beitrag von „John Doe“ vom 27. Juli 2015, 08:23

if you want to use the internal grafics take the nvidia card out of the Maschine and set the bios to internal grafics before you take the nvidia out