

Erledigt

## DSDT fix Z87MX-D3H (OZ167X)

Beitrag von „nikoZ“ vom 28. Februar 2016, 13:54

Activating ErP disables WOL and I NEED WOL.

Another user from another forum said that it solved that problem with USB ports by disabling CPU PLL from Advanced CPU Features in BIOS.