

Erledigt

OZMOSIS REQUEST THREAD / Ozmosis Anfragen [1. Beitrag beachten!]

Beitrag von „al6042“ vom 18. Mai 2017, 22:31

I think I know what's your issue here...

With the flashing of the Ozmosis flavored BIOS the IGPU/IGFX is activated and set as "Initial Display Output".

In that case you have only two options:

1.

use ESC-key while starting the box until the complete screen turns red, than use the DEL-key to get into your BIOS.

2.

If that doesn't work, remove the GT 640 and connect your monitor to the onboard graphics outlet, then use the DEL-key to get into your BIOS.

If you've reached the BIOS, use the following settings:

Initial Display Output : IGFX or the Slot which should contain the GT 640, which should be "PCIe 1 Slot"

If you also want the internal Graphics (HD4600) to work, you should set:

Intel Processor Graphics : Enabled

Intel Processor Graphics Memory: 32M

[DVMT](#) Total Memory Size : MAX