

Erledigt

RX 460 not working

Beitrag von „griven“ vom 25. Mai 2017, 14:58

In case of OZ as loader you need to pass the correct Framebuffer and enable OZ ATIIInjection as well. I think for RX460 something like this should do the trick:

Code

1. `sudo nvram 1F8E0C02-58A9-4E34-AE22-2B63745FA101:DisableAtiInjection=%00`
2. `sudo nvram 1F8E0C02-58A9-4E34-AE22-2B63745FA101:AtiFramebuffer=Baladi`