

**Erledigt**

## macOS sierra in Thinkpad E560 help needed

Beitrag von „Web Developer“ vom 10. September 2017, 21:40

[@al6042](#) Now when I connect the Charger the Battery indicator not showing that the Charger is connected!

also the Red Battery problem is not solved,

and I have these two messages in the log:

Code

1. kernel ACPIBatteryManager: WARNING! fMaxCapacity > fDesignCapacity. adjusted fMaxCapacity from 4647, to 4400
- 2.
- 3.
4. default 22:34:30.061785 +0300 kernel ACPIBatteryManager: WARNING! fCurrentCapacity > fMaxCapacity. adjusted fCurrentCapacity from 4633, to 4400