

Erledigt

Gigabyte GA-Z87X-UD7 TH Sound PKG

Beitrag von „kuckkuck“ vom 24. Oktober 2018, 13:51

Download AppleALC and Lilu.kext and place them in EFI/Oz/Darwin/Extensions/Common. The put the bootarg `alcid=1` into your defaults.plist and remove the entry "FirmwareVendor" from your defaults.plist.

Do a NVRam reset an Sound should work.