

**Erledigt**

## **Dell Precision T3500 High Sierra / Mojave**

**Beitrag von „gocard“ vom 4. April 2019, 18:00**

Hallo liebe Leute,

während DHL die neue Graka immer wieder ins Lager zurückfährt anstatt sie zuzustellen, versuche ich derweil den Rechner zu Ausschalten zu bewegen.

In Erwartung einer RX 580 habe ich auch gleich auf Mojave 10.14.4 gewechselt.

Lan, Audio, USB, Versionsupdate und Neustart funktioniert alles.

Sleep und Ausschalten leider noch nicht.

Das Ausschalten funktioniert leider nur per Knopfdruck.

Wenn ich es mit >Apfel >ausschalten versuche, bleibt der Prozess immer an dieser Stelle stehen:

```
vm_map_delete: map <ptr> [0x11a6db000...0x11ad96000] nothing at 0x11a6db000
build_signal_reason: unable to allocate signal reason buffer.
Failed to send exception EXC_CORPSE_NOTIFY, error code: 5 for pld 264
vm_map_delete: map <ptr> [0x1066ca000...0x1066cb000] nothing at 0x1066ca000
vm_map_delete: map <ptr> [0x10d742000...0x10d747000] nothing at 0x10d742000
vm_map_delete: map <ptr> [0x7000041af000...0x700004232000] nothing at 0x7000041af000
vm_map_delete: map <ptr> [0x70000ffb0000...0x70001003b000] nothing at 0x70000ffb0000
Thu Apr  4 16:51:04 2019 MacDells-lMac.local com.apple.xpc.launchd[1] (com.apple.xpc.launchd.domain.system) <Not
Thu Apr  4 16:51:06 2019 MacDells-lMac.local com.apple.xpc.launchd[1] <Notice>: Generating report...
Thu Apr  4 16:51:07 2019 MacDells-lMac.local com.apple.xpc.launchd[1] <Notice>: Report generated in 1 seconds.
bash: /private/var/install/shutdown_installer_tasks: No such file or directory
bash: /private/var/install/deferred_install: No such file or directory
Thu Apr  4 16:51:08 2019 MacDells-lMac.local com.apple.xpc.launchd[1] (com.apple.xpc.launchd.domain.system) <Not
Thu Apr  4 16:51:08 2019 MacDells-lMac.local com.apple.xpc.launchd[1] (com.apple.xpc.launchd.domain.system) <Not
IOConsoleUsers: gIOScreenLockState 3, hs 0, bs 0, now 0, sm 0xe0000255
GTrace synchronization point 114
syncing disks... Killing all processes

continuing
apfs_stop_bg_work:773: System is shutting down stop any bg work
Unmount of /home failed (45)
Unmount of /net failed (45)
apfs_vfsop_unmount:1696: /dev/disk1: unmounting volume 'VM'
apfs: total mem allocated: 48688958 (46 mb):
apfs_vfsop_unmount:1936: all done. going home. (numMountedAPFSVolumes 1)
apfs_vfsop_unmount:1696: /dev/disk1: unmounting volume 'NoJaveSSD'
sanity_check_allocated_blocks:263: fs_alloc_count mismatch: fs root nodes 45889 extent 764 omap 888 snap_meta 1 er
apfs: total mem allocated: 0 (0 mb):
apfs_vfsop_unmount:1936: all done. going home. (numMountedAPFSVolumes 0)
done
CPU halted
GTrace synchronization point 118
: in6_eventhdlr_callback Event IN6_NDP_RTR_EXPIRY received for fe80::f2f2:49ff:fefd:1092
```

Ich habe aus anderen Beiträgen auch schon Lösungsvorschläge probiert:

- das Entfernen von rc.boot.d und rc.shutdown.d (aus /etc/)
- Acpi > FixShutdown
- Terminal

```
sudo rm -rf /var/folders/*
```

```
sudo shutdown -r now
```

!!! bewirkte Löschung der EFI-Partition !!! musste alles komplett neu installieren

- Entfernen von GenericUSBXHCI.kext aus S/L/E (gibt es bei mir nicht)

Das hat leider alles nicht funktioniert.

Hat vielleicht jemand eine Idee, wie man Sleep und Ausschalten hinbekommt?

Hier mal der aktuelle EFI-Ordner:

[EFI.zip](#)

Vielen Dank und viele Grüße

Edit:

Nach einem Wechsel des SMBios auf iMac 18.3 funktioniert nun schon mal das Ausschalten.