


# Bluetooth tot nach Update auf 10.15.2

Beitrag von „Hubert1965“ vom 27. Dezember 2019, 18:15

Das sieht bei mir so aus:



The screenshot shows the Hackintool v2.8.8 interface. The top menu bar includes: Info, Patch, Bootloader, NVRAM, Installed, Displays, Audio, USB (selected), Disks, PCI, Power, Calculator, Tools, and Logs. The main content area is divided into two sections:

**USB Controller:**

Type	Name	Serie	Vendor ID	Geräte ID
XHC	Cannon Lake PCH USB 3.1 xHCI Host Controller	300	0x8086	0xA36D

**USB Anschlüsse:**

Name	Konnektor	Anschl...	Dev Speed	Gerät
HS01	USB3	⇅	0x01	Unknown
HS02	USB3	⇅	0x02	Unknown
HS03	USB3	⇅	0x03	Unknown
HS04	USB3	⇅	0x04	Unknown
HS05	USB3	⇅	0x05	Unknown
HS06	USB3	⇅	480 Mbps	USB2.0 Hub
HS07	USB3	⇅	0x07	Unknown
HS08	USB3	⇅	0x08	Unknown
HS09	USB3	⇅	0x09	Unknown
HS10	USB3	⇅	0x0A	Unknown
HS11	USB3	⇅	0x0B	Unknown
HS12	USB3	⇅	12 Mbps	Bluetooth USB Host Controller
HS13	USB3	⇅	480 Mbps	Keyboard Hub
HS14	USB3	⇅	0x0E	Unknown
USR1	USB3	⇅	0x0F	Unknown