


Erledigt

[Need Help] H87 Clover "End RundoSeed" +++ and reboot

Beitrag von „June“ vom 25. März 2020, 12:44

I don't know why the resolution like this:



```
UEFI Interactive Shell v2.1
EDK II
UEFI v2.31 (American Megatrends, 0x0004028E)
Mapping table
  FS0: Alias(s):HD18b0e0b:;BLK3:
-78a8-48a0-8c98-66ad0d62406c,0x28,0x64000)
  FS1: Alias(s):HD18b0e0c:;BLK4:
-fcaa-4a0a-ba83-6d046bc051b4,0x64028,0xa89038)
  BLK2: Alias(s):
    PciRoot(0x0)/Pci(0x1d,0x0)/USB(0x1,0x0)/USB(0x4,0x0)
  BLK0: Alias(s):
    PciRoot(0x0)/Pci(0x1,0x0)/Pci(0x0,0x0)/?
  BLK1: Alias(s):
765-01a46935531f,0x1000,0x1dcf2000)
Press ESC in 2 seconds to skip startup.nsh
Shell> ir
'ir
script file.
Shell> dir
```

I can't see all screen