

Erledigt **USB Maus funktioniert nicht.**

Beitrag von „al6042“ vom 11. April 2020, 13:01

Es ist egal ob per Clover oder OpenCore, aber die Ports, an denen Maus, Tastatur oder ein entsprechender Dongle für den kabellosen Betrieb genutzt werden, sollten meines Erachtens immer auf "Internal" stehen.

So läuft das bei mir und macht auch keine Stress bei Sleep oder ähnlichen Features:

Type	Name	Location ID	Part	Connector	Dev Speed	Device
XHC	HS05	0x14100000	0x05	USB2	Unknown	
XHC	HS06	0x14200000	0x06	USB2	480 Mbps	USB2.0 Hub
XHC	HS09	0x14300000	0x09	USB2	Unknown	
XHC	HS10	0x14400000	0x0A	USB2	Unknown	
XHC	HS12	0x14500000	0x0C	Internal	12 Mbps	Bluetooth USB Host Controller
XHC	HS13	0x14600000	0x0D	Internal	12 Mbps	USB Receiver
XHC	HS14	0x14700000	0x0E	Internal	480 Mbps	C922 Pro Stream Webcam
XHC	SS01	0x14800000	0x11	USB3	Unknown	
XHC	SS02	0x14900000	0x12	USB3	Unknown	
XHC	SS03	0x14A00000	0x13	USB3	Unknown	
XHC	SS04	0x14B00000	0x14	TypeC+Be	Unknown	
XHC	SS05	0x14C00000	0x15	TypeC	Unknown	
XHC	SS06	0x14D00000	0x16	TypeC	Unknown	
XHC	SS07	0x14E00000	0x17	USB3	Unknown	
XHC	SS08	0x14F00000	0x18	USB3	Unknown	