

X299 Tutorial - ASUS WS X299 SAGE/10G (Hilfe und Diskussionen)

Beitrag von „kaneske“ vom 14. Oktober 2020, 15:23

It is not the APFS Partition the UEFI must show, it's the ESP of it.

Have you tried to choose it Manually by pressing F8 whilst booting and choose the ESP Partition of your NVME and boot up?

Note: unplug your stick before this.