

X299 Tutorial - ASUS WS X299 SAGE/10G (Hilfe und Diskussionen)

Beitrag von „DSM2“ vom 23. Oktober 2020, 13:30

And why do you enter enp225s0f0 then ?

My guide explains the process and also tells you to check your address and adapt the commands accordingly because my ENP may be different from yours.

Commands would be in your case :

```
sudo ethtool -E enp179s0f0 magic 0x15638086 offset 0x242 value 0x0a
```

```
sudo ethtool -E enp179s0f0 magic 0x15638086 offset 0x243 value 0x00
```

```
sudo ethtool -E enp179s0f1 magic 0x15638086 offset 0x242 value 0x0a
```

```
sudo ethtool -E enp179s0f1 magic 0x15638086 offset 0x243 value 0x00
```