

Problem mit Ruhezustand

Beitrag von „phil48“ vom 6. Mai 2021, 11:00

[Zitat von anonymous writer](#)

Gibt dir dieser Befehl im Terminal einen Hinweis auf das Problem?

Code

1. `pmset -g log | grep -i failure`

er gibt mir hier:

```
"Failure during sleep: 0xFFFFFFFF0000001F : EFI/Bootrom Failure after last point of entry to sleep"
```

Habe über Google verschiedenes gefunden (Legacy im Bios aktivieren, Serial deaktivieren, ResetHwSig in der Config auf on..) hat bisher nichts geändert.

Vielleicht helfen die Logs?:

Code

1. ~ % `pmset -g assertions`
2. 2021-05-06 10:54:06 +0200
3. Assertion status system-wide:
4. BackgroundTask 0
5. ApplePushServiceTask 0
6. UserIsActive 1
7. PreventUserIdleDisplaySleep 0
8. PreventSystemSleep 0
9. ExternalMedia 0
10. InternalPreventDisplaySleep 1
11. PreventUserIdleSystemSleep 1
12. NetworkClientActive 0
13. Listed by owning process:
14. pid 162(coreaudioid): [0x0000002600018145] 00:04:58 PreventUserIdleSystemSleep
named: "com.apple.audio.SonarworksEngine:0.context.preventuseridlesleep"
15. Created for PID: 418.
16. pid 162(coreaudioid): [0x0000002600018105] 00:04:58 PreventUserIdleSystemSleep
named: "com.apple.audio.AppleUSBAudioEngine:Native Instruments:Komplete Audio

- 6:38347201:1,2.context.preventuseridlesleep"
17. Created for PID: 418.
 18. pid 116(hidd): [0x0000001100098073] 00:00:00 UserIsActive named: "com.apple.iohideeventsystem.queue.tickle serviceID:1000003fb name:AppleUserHIDEventSe product:USB Receiver eventType:3"
 19. Timeout will fire in 960 secs Action=TimeoutActionRelease
 20. pid 71(powerd): [0x0000000400108003] 00:04:50 InternalPreventDisplaySleep named: "com.apple.powermanagement.delayDisplayOff"
 21. Timeout will fire in 10 secs Action=TimeoutActionTurnOff
 22. Kernel Assertions: 0x4=USB
 23. id=500 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.1a100000 owner=IOUSBHostDevice
 24. id=501 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.1d100000 owner=IOUSBHostDevice
 25. id=504 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14300000 owner=eLicenser
 26. id=505 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14500000 owner=USB 2.0 Hub
 27. id=507 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14400000 owner=Komplete Audio 6
 28. id=508 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14530000 owner=FAME Tweak 61
 29. id=509 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14510000 owner=USB Receiver
 30. id=510 level=255 0x4=USB mod=01.01.70, 01:00
description=com.apple.usb.externaldevice.14540000 owner=Wireless Mouse
 31. Idle sleep preventers: IODisplayWrangler

Alles anzeigen

Code

1. ~ % pmset -g
2. System-wide power settings:
3. Currently in use:
4. standby 0
5. Sleep On Power Button 1
6. womp 0
7. hibernatfile /var/vm/sleepimage
8. powernap 0
9. networkoversleep 0
10. disksleep 0
11. standbydelayhigh 86400
12. sleep 16 (sleep prevented by coreaudiod, coreaudiod)

13. autopoweroffdelay 259200
14. hibernatemode 0
15. autopoweroff 0
16. ttyskeepawake 1
17. displaysleep 16
18. highstandbythreshold 50
19. standbydelaylow 86400

Alles anzeigen

Habe die config.plist mal angefügt.

Aber was ich noch immer seltsam finde ist, dass der Ruhezustand einwandfrei funktioniert wenn ich über das Apfel-Symbol oben links gehe und auf "Ruhezustand" klicke. Nur der automatische Ruhezustand und über die Shortcuts amt+cmd+eject funktionieren nicht, bzw. er wacht dann nicht mehr richtig auf.