

Asus B550 Bootloop

Beitrag von „fabiosun“ vom 17. November 2022, 16:08

you have to find your GPU path in ioreg

you can use attached app:



Edit:

post path an IOREG

Edit 2

Here seems to be an error

Code

1. DefinitionBlock ("", "SSDT", 2, "ACDT", "BRG0", 0x00000000)
2. {
3. External (_SB_.PCI0.GPP8.X161.SWD_.VGA_, DeviceObj)
- 4.
5. Scope (_SB.PCI0.GPP8.X161.SWD.VGA)