

Ryzentosh - Ryzen 5 3600 - ASUS PRIME B450M-K II - AMD 6600 XT (Er Startet nicht)

Beitrag von „fabiosun“ vom 17. November 2022, 20:13

have you tried to disconnect ethernet cable?

Debug is not useful it is written before your hang

Check also your [BIOS settings](#):

4G ON

UEFI ON

CSM OFF