

Ryzentosh - Ryzen 5 3600 - ASUS PRIME B450M-K II - AMD 6600 XT (Er Startet nicht)

Beitrag von „fabiosun“ vom 17. November 2022, 20:43

try this, if it doesn't work add only SSDT-EC in ACPI folder and declare in config.plist (take it from old EFI)

If no one helps you meanwhile, tomorrow I will try to understand why it is not working