

Ryzentosh - Ryzen 5 3600 - ASUS PRIME B450M-K II - AMD 6600 XT (Er Startet nicht)

Beitrag von „fabiosun“ vom 19. November 2022, 15:25

[Zitat von Ninjiopl](#)

So i go to the BIOS and your right "Above 4G Decoding" was Disabled, so I Enable it, but the other settings were alright

use above efi you posted and take a photo where it hangs