

OC DELL Latitude E6420

Beitrag von „soxongful“ vom 3. Oktober 2023, 10:15

Hello! Today I have two questions for you. First I turned off [sip](#) in recovery but opencore still says it's enabled, secondly I added the value `amfi_get_out_of_my_way=0x1` to config.plist then I can't boot into opencore, why is the config.plist file Yours cannot be edited