

# Der Mauszeiger (USB) bewegt sich ruckelnd

Beitrag von „apfel-baum“ vom 7. Mai 2024, 13:06

in twice, change your hardwaresetup take a look at the hardwarecenter -> [Hardware Center](#) or stay with clover, your version of osx and /or look for the manual <https://github.com/5T33Z0/Clover-Crate> for example.

for newer clover version-configuration setup

lg 😊