

Sequoia und Bluetooth

Beitrag von „tackerJim“ vom 3. November 2024, 18:42

[Zitat von schrup21](#)

Du meinst warum Delete: weil damit bootargs sauber "entladen" werden, d.h. wenn man etwas in Add nicht mehr braucht, muss kein NVRAM Reset durchgeführt werden (z.B. wenn eine neue Version der Kexte eingebracht ist, die diese Parameter nicht mehr brauchen).

Also wenn du inkl. der Kexte alles so eingerichtet hast, inkl. der beiden NVRAM Keys, gibt's keinen Grund warum BT nicht läuft - außer vielleicht eine Inkompatibilität oder was ganz anderes ist die Fehlerursache (wie die beschriebene Restarts bei Verwendung der USB Ports)

Laut MSI ist eine Wifi Bluetooth Combo Karte im M.2 Slot verbaut - hast du die entfernt oder nur im Bios deaktiviert?

Ich habe nur Bluetooth deaktiviert.

[Zitat von fabiosun](#)

[schrup21](#) User need airdrop and HAndoff and i think common apple features..so his wifi had to be working for all these features

[tackerJim](#)

Internal BT and PCIe Broadcom bt may differ in USB port they both use

Also, have you conneted USB PCIe Broadcom cable to your motherboard?

Yes i have connected the cable.