

VERSION 167X-XMAX

Beitrag von „WuiOne Cell“ vom 21. September 2020, 12:50

I want to know what VERSION 167X-xmax means.

[I want to know what Version 167X-Mass](#) means.

[I want to know what](#) Version 1669m means.

I want to know what Version 1669m means.

I want to know what Version 1479m means.

I want to know what Version 894m means.

What's the difference between them?

Thank you very much for your reply.

Beitrag von „Raptortosh“ vom 21. September 2020, 12:54

This is ozmosis Bootloader, Which ja used since Mojave.

[Ozmosis mit macOS Catalina 10.15 - OZ167X-XMAX \(extended\)](#)

[macOS Mojave Ozmosis BETA – OZ167X-XMAX](#)

[Ozmosis Patch macOS Mojave](#)

And the others are old ozmosis Versions..

167X-mass (non patched) = up to El capitan, but Bug fixed (1669 has some Bugs).

1669M = up to El Capitan

1479, 894 = up to Yosemite