


Gigabyte Z390 DESIGNARE: OpenCore-EFI-Ordner und Anleitung

Beitrag von „macdream“ vom 5. August 2021, 11:26

Ich habe die beiden Kexte in der config.plist hinten "angehängt":

Kernel	Dictionary	0	7 items
Add	Array	0	13 items
Item 0	Dictionary	0	8 items
Item 1	Dictionary	0	8 items
Item 2	Dictionary	0	8 items
Item 3	Dictionary	0	8 items
Item 4	Dictionary	0	8 items
Item 5	Dictionary	0	8 items
Item 6	Dictionary	0	8 items
Item 7	Dictionary	0	8 items
Item 8	Dictionary	0	8 items
Item 9	Dictionary	0	8 items
Item 10	Dictionary	0	8 items
Item 11	Dictionary	0	8 items
Arch	String	0	x86_64
BundlePath	String	0	CPUFriendDataProvider.kext
Comment	String	0	CPUFriendDataProvider
Enabled	Boolean	0	YES
ExecutablePath	String	0	
MaxKernel	String	0	
MinKernel	String	0	12.0.0
Path	String	0	Contents/Info.plist
Item 12	Dictionary	0	8 items
Arch	String	0	x86_64
BundlePath	String	0	CPUFriend.kext
Comment	String	0	CPUFriend
Enabled	Boolean	0	YES
ExecutablePath	String	0	Contents/MacOS/CPUFriend
MaxKernel	String	0	
MinKernel	String	0	12.0.0
Path	String	0	Contents/Info.plist

und natürlich noch die Kexte in das entsprechende Verzeichnis kopieren...



Das sollte es gewesen sein.